

# Crank Case

| Photo   | Item#      | Description   |       |
|---|------------|---|-------|
|    | CK-01E-L   | <b>50-110cc<br/>Electrical Start<br/>Engine Crank Case<br/>with Bearings</b>        | Left  |
|   | CK-01E-R   |   | Right |
|    | CK-02A-L   | <b>50-110cc<br/>ATV Electrical Start<br/>Crank Case (Reverse)<br/>with Bearings</b> | Left  |
|   | CK-02A-R   |   | Right |
|    | CK-03K-L   | <b>50-110cc Kick Start<br/>Crank Case<br/>with Bearings</b>                         | Left  |
|  | CK-MP      | <b>Starter Motor Mounting Plate</b>   |       |
|  | CKL-125-L  | <b>Lifan 125cc<br/>Electrical Start<br/>Crank Case with Bearings</b>                | Left  |
|   | CKL-125-R  |   | Right |
|  | CKL-125K-L | <b>Lifan 125cc<br/>Kick Start<br/>Crank Case with Bearings</b>                      | Left  |
|   | CKL-125K-R |   | Right |
|  | CKD-125K-L | <b>Ducar 125cc<br/>Kick Start<br/>Crank Case with Bearings</b>                      | Left  |
|   | CKD-125K-R |   | Right |
|  | CKD-125-L  | <b>Ducar 125cc<br/>Electrical Start<br/>Crank Case with Bearings</b>                | Left  |
|   | CKD-125-R  |   | Right |

# Crank Case

| Photo   | Item#      | Description   |       |
|---|------------|---|-------|
|    | CKL-140K-L | Lifan 140cc<br>Kick Start<br>Crank Case with Bearings | Left  |
|   | CKL-140K-R |   | Right |
|    | CKD-140K-L | Ducar 140cc<br>Kick Start Crank Case<br>with Bearings | Left  |
|   | CKD-140K-R |   | Right |
|    | CKV-10-L   | 150-250cc Crank Case<br>with Bearings                 | Left  |
|   | CKV-10-R   |   | Right |
|  | CKB-A-L    | Loncin CB250cc<br>Air Cooled Engine<br>Crank Case     | Left  |
|   | CKB-A-R    |   | Right |
|  | CKB-W-L    | Loncin CB250cc<br>Water Cooled Engine<br>Crank Case   | Left  |
|   | CKB-W-R    |   | Right |
|  | CKG-20A    | GY6/ ATV /Buggy<br>Crank Case/Left                    |       |
|  | CKG-21S    | GY6 125-150cc<br>Scooter Crank Case/Left              |       |